Butler COLLECTION

PARK BENCH WITH SOLAR LIGHTS

Model 95845

SETUP AND OPERATION INSTRUCTIONS

Due to continuing improvements, actual product may differ slightly from the product described herein.

Distributed Exclusively by HARBOR FREIGHT TOOLS®

3491 Mission Oaks Blvd., Camarillo, CA 93011

Visit our website at: http://www.harborfreight.com

TO PREVENT SERIOUS INJURY, READ AND UNDERSTAND ALL WARNINGS AND INSTRUCTIONS BEFORE USE.

Copyright© 2007 by Harbor Freight Tools®. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

For technical questions or replacement parts, please call 1-800-444-3353.

SPECIFICATIONS

Bench Dimensions	48” Long x 15-1/4” Deep x 14-1/4” High (Back Rest) 16” High from Ground
Light Panels	Qty. 6 “V” Design Crinkled Panels with LED Lighting
Solar Panel Mount	9.33 Ft. Long Cord
Batteries	3 Rechargeable “AA” 1.2V 500mAH (Included)
Net Weight	31.1 Lbs.
Maximum Weight Capacity	400 lb.

Save This Manual

You will need the manual for the safety warnings and precautions, assembly instructions, operating and maintenance procedures, parts list and diagram. Keep your invoice with this manual. Write the invoice number on the inside of the front cover. Keep the manual and invoice in a safe and dry place for future reference.

GENERAL SAFETY RULES

⚠WARNING!

READ AND UNDERSTAND ALL INSTRUCTIONS
Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.
SAVE THESE INSTRUCTIONS

WORK AREA

1. **Keep your work area clean and well lit.** Dark areas invite accidents.
2. **Keep bystanders, children, and visitors away while assembling this product.**

PERSONAL SAFETY.

1. **Replace or repair damaged or worn parts immediately.**
2. **Do not exceed the max. weight capacity of 400 lb.** Injury could occur if the bench is overloaded or unbalanced.
3. **Do not stand or climb on this bench.**
4. **Do not set up this product if under the influence of alcohol or drugs**. Read warning labels on prescriptions to determine if your judgement or reflexes are impaired while taking drugs. If there is any doubt, do not attempt to use this product.
5. **Use eye protection when assembling this product.** Wear ANSI-approved safety impact eye goggles when assembling this product.
6. **Two adults are better at assembling this product.** Be careful not to pinch fingers between the wooden seat slats.

7. **Do not allow children to play on this Park Bench.** Children under 10 years of age should be accompanied by an adult. Do not let children stand on this Park Bench. The Bench could topple if overloaded or if weight is distributed unevenly.

8. **Do not let children or animals near the power source of this product.**

9. **Check for damaged parts.** Before using this product, carefully check that it will operate properly and perform its intended function. Check for damaged parts and any other conditions that may affect its operation. Service and maintenance should be performed by a qualified technician. LED lights are designed to last for a very long time. They should not need to be replaced.

10. **Do not force any part of the assembly and do not overtighten the bolts.** Serious damage can occur.

11. **Use this product ONLY with the Solar Panel with Stake and Cord that accompanies this product.** Do not use any other accessory.

12. **The Solar Panel with Stake must be placed where sunlight can recharge the Solar Lights.** Placing it in a shady area or near a street light will cause the Solar Park Bench to not light up.

13. **When placing the Solar Panel with Stake into the ground, avoid any electrical wires or plumbing underground that are not visible.**

14. **Avoid accidently cutting the electrical cord attached to the Solar Panel with Stake and to the Bench.** This electric cord could cause tripping or be accidently cut by a lawn mower or gardening equipment. Avoid water around the cord. Always be cautious and avoid electrical shocks. Do not use if the cord is frayed or worn. If cord is damaged, contact a qualified technician to replace the electric cord.

15. **Use only on a flat, level surface that is capable of withstanding the weight of the Park Bench (31 lb.) and the Bench's max weight capacity (400 lb.)**

16. **The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.**

SAVE THESE INSTRUCTIONS.

UNPACKING

When unpacking, check to make sure that the item is intact and undamaged. If any parts are missing or broken, please call Harbor Freight Tools at the number on the cover of this manual as soon as possible.

ASSEMBLY

We suggest you assemble the unit on a soft surface to avoid damage to the finish.



FIGURE 1

1. Attach the five wooden Seat Slats (3) onto the right and left Arm Rests (1) using the Screws (9) on the top side of the Slats and the Washers (8) and Nuts (10) on the underside. Hand tighten. ***See Figure 1.***



FIGURE 2

2. Attach the Seat Brace (5) to the wooden Seat Slats (3) using the Tap Screws (7). Tighten all hardware after assembly. ***See Figure 2.***

Note: It may become necessary to enlarge the holes in the Seat Slats (3). Clear the hole of paint or varnish by sliding a bolt through the hole or using a drill (not included).



FIGURE 3

3. Attach the Back Assembly with LED Lights (2) to the Armrest (1), right and left. Use the four Screws (6) through the brackets on both Armrests (1) and through the Back Assembly (2). Tighten Screws. ***See Figure 3.***

4. To secure the Bench to the ground, hammer the Ground Nails (9) through the pre-drilled holes at the base of each leg. Make sure that when hammering nails into ground that the area is clear of any underground wires or cables.

OPERATING THE PARK BENCH



FIGURE 4

1. Place the Park Bench in a location where the sun can shine on the Solar Panel. Attach the Power Cord to the Solar Panel with Stake (4). Anchor or bury the Power Cord to avoid someone tripping over the wires. (Power Cord not shown above. See assembly drawing on page 8). ***See Figures 3 & 4.***

2. Press the Solar Panel with Stake (4) into the Ground.



Power Cord Leading to the Solar Panel with Stake (4) (not shown)

FIGURE 5

3. **Warning: Avoid any electrical wires or cables hidden underground.**

4. Use the two side knobs on the side of the Solar Panel (4) to tilt the Solar Panel to absorb the suns rays for charging. ***See Figure 4 on page 5.***

5. With the Cord from the back of the Park Bench connected to the Solar Panel with Stake (4), allow eight to twelve hours for the charge from the sun to take affect.

6. Have the Power Switch (11) that is on the back of the Solar Panel (4) in the "ON" position. Leave it in the "ON" position all the time. The sensor shuts it off when daylight comes. If you do not want the Park Bench to light up at night, turn the Switch to the "OFF" position. ***See Figure 6, next page.***

6. Shade will limit the amount of light you get from your product. The LED Bulbs in the Seat Back Assembly (2) are long lasting and non-replaceable. After being in the sunlight for at least 8 hours of charging time and the light does not come on, check your batteries. The battery life is about one year in normal conditions

REPLACING THE BATTERIES

1. The batteries are standard "AA" 500 mAH rechargeable batteries. If the lights remain dim or do not come on at all, replace the batteries.

PARTS LIST



Part	Description	Q'ty
1	Arm Rest (right/left)	2
2	Back Assembly with LED Lights and Cord	1
3	Wood Slat	5
4	Solar Panel with Stake	1
5	Seat Brace	2
6	Screw (6 X 15mm)	5
7	Tap Screw (5 X 15mm)	10
8	Washer	10
9	Screw (6 X 32mm)	10
10	Nut	10
11	Power Switch	1
12	Ground Nail	4

ASSEMBLY DIAGRAM



Note: Some parts are listed as shown for illustration purposes only and are not available individually as replacement parts.